

CONTROL PANEL



- A. **Power Switch** – Powers the machine on and off.
- B. **Elevation** – Adjusts the ball trajectory up and down.
- C. **Vertical Switch** – Turns on and off the random vertical oscillation. Available on Elite Two and Elite Three machines only.
- D. **Horizontal Switch** – Turns on and off the random horizontal oscillation.
- E. **Two-line Switch** – Turns on the 2-line function for narrow and wide options. Available on Elite Three only.
- F. **Remote Switch** – Activates the remote control handheld keyfob. If you did not purchase a remote, this switch is not active until you upgrade your machine. An upgrade is available from your dealer or direct from the factory.
- G. **Reset Button** – The reset button pops out in the event of a malfunction. If the reset button pops out, please refer to the Troubleshooting section on page 6.
- H. **Basic Charger Jack** – This jack is for the basic charger.
- I. **Feed On LED** – LED will light up when the feed motor begins to turn.
- J. **Feed Knob** – Adjusts feed interval between 2-12 seconds. Turn completely counter-clockwise to turn off the feed.
- K. **Speed Knob** – Adjust the speed from 10-80 mph.
- L. **Spin Knob** – Controls amount of spin on the ball.
- M. **Battery Status Indicator** – LED indicates battery charge.



OPERATING INSTRUCTIONS

Court Placement

To ensure the best position and widest range of sweep, use the white court placement indicator on the bottom of the machine and place the machine at the center mark on the baseline.

If desired, moving the machine closer to the net will narrow the sweep or moving it back from the baseline will widen it. To sweep the machine left to right, turn on the horizontal sweep and turn off when the machine is in desired position. It is not necessary to pick up and reposition the machine.

Ball Consistency

A mixture of new and old balls will produce inconsistent ball throws. Pressureless balls are recommended for use with a ball machine.

Power the Machine

Turn the machine on using the Power Switch on the control panel.

- Set the feed anywhere from 2-12 seconds, where 12 seconds is the slowest feed rate setting.
- Put 3-4 balls in the machine and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed, and spin are appropriate; adjust if necessary. Once you have set the machine up properly, turn the machine off; load the hopper full of balls, and turn on the machine.
- The 20 second delay will allow you time to walk to the other side of the court and position you for the first shot.
- To turn off the feed, rotate the knob fully counterclockwise without turning machine off. This will save battery capacity and allow time to retrieve balls on the court.

Two-Line Oscillation Setup (Available with Elite Three Only)

The two-line function automatically shoots to two preset locations allowing you to practice alternating forehand and backhand shots. You may choose 2-line narrow or wide for added versatility. **NOTE:** The Ball Hopper **MUST** have balls in it for the 2-line Oscillation feature to work.

- Fill the hopper, then turn the Power Switch ON.
- Set desired speed. Turn on horizontal oscillation, select Narrow or Wide settings.
- For a 4-second interval per ball, set the feed from 2-8 seconds.
- For an 8-second interval per ball, set the feed from 10-12 seconds.
- **REMINDER:** There will be a 20 second delay to allow you to get into position.

